

Volkswagenwerk AG



Troubleshooting Guide

**for Engines with
Electronic Fuel Injection
MPC (manifold pressure controlled)**

Type 3/all
Type 4/Manual Transmission
Type 4/Automatic Transmission
(up to Oct. 1973)

Contents

Starting trouble

- Engine does not start
- Cold engine does not start
- Hot engine does not start
- Engine starts but stops again after a short time

Idling trouble

- Rough idle during warm-up
- Hunting (surging) at idle at all temperatures
- Hot engine stalls at idle
- Rough idle in driving range, (Automatic Transmission)
- Idle irregular (like misfiring)
- Idle too high

Hesitation trouble

Poor output, top speed too low

Fuel consumption too high

Engine misfiring

- Misfiring only when electrical components are switched on
- Misfiring at all times

CO value too high

Wiring diagrams

Starting trouble

Idling trouble

Hesitation trouble


Poor output/
top speed too low

Fuel consumption too high

Engine misfiring

CO value too high

Wiring diagram



VW 1218
(ASE 000050)


Introduction Start here

How does this troubleshooting guide work?

Together with the necessary equipment – mainly the VW 1218 tester – this guide should help you to locate trouble in the fuel injection system quickly


Finding your way

- Step 1: Verify the complaint. Check the customer complaint to determine if a problem really exists. Road test, and if possible have the customer show you what happens. If the problem exists, note the symptoms.
- Step 2: Find symptom on contents page
- Step 3: Follow arrow to thumb index, from there to the right page



How to check

- Step 1: Be sure test conditions check out OK
- Step 2: Upper box lists most probable trouble. Start to check here first.
- Step 3: Result of check guides you to next box or arrow until trouble is found and corrected.



Engine does not start

Cold engine does not start

Hot engine does not start

Engine starts but stops
again after a short time



VW 1218
(ASE 000 050)

Introduction

Start here

How does this troubleshooting guide work?



Together with the necessary equipment – mainly the VW 1218 tester – this guide should help you to locate trouble in the fuel injection system quickly

Finding your way

- Step 1: Verify the complaint. Check the customer complaint to determine if a problem really exists. Road test, and if possible have the customer show you what happens. If the problem exists, note the symptoms.
- Step 2: Find symptom on contents page
- Step 3: Follow arrow to thumb index, from there to the right page

How to check

- Step 1: Be sure test conditions check out OK
- Step 2: Upper box lists most probable trouble. Start to check here first.
- Step 3: Result of check guides you to next box or arrow until trouble is found and corrected.



Engine does not start

Cold engine does not start

Hot engine does not start

Engine starts but stops again after a short time

Starting trouble

Misfiring trouble

Resistive trouble

Power output/rev speed too low

Fuel consumption too high

Engine misfiring

CO value too high

Wiring diagram

Note

Following defects may be found despite visible sparking at spark plug connectors:

- Distributor cap (damp, cracked, burnt by tracking)
- Rotor defective
- Loose connections on coil
- Spark plugs or connectors defective
- Ignition timing incorrect (breaker points)
- Ignition cables poorly connected
- Arcing at ignition cables on distributor (through the rubber caps)
- Voltage at terminal 15 on coil too low (minimum = 9 volts)
- Condenser defective



Check cold start valve for sealing

Note

- Detach cold start valve from intake air distributor but leave it connected to ring main.
- Switch ignition on and off several times and check if fuel is delivered.

**Note**

Thermoswitch should not show any continuity above specified cut-in temperature.

Cut-in temperatures are:

- 311 906 161 = -12 to -18°C (10 to 0°F) (Aug. 67 to July 69)
- 311 906 161A = 0 to +10°C (32 to 14°F) (Aug. 69 to March 70)
- 311 906 161C = -6 to -14°C (21 to 7°F) (from April 70)
- 311 906 161B = -2 to -8°C (28 to 18°F) (Service use only up to March 70)

**Engine does not start****Test conditions:**

- Correct starting procedure.
- Fuel in tank.
- Starter is turning fast enough (battery voltage).

Faults in ignition system

Check ignition system and eliminate any defects.

Caution

Sparks at the plug connectors do not always indicate that ignition system is in order.

Engine does not start

Engine starts

Faults in fuel system

Check pressure in ring main with pressure gauge while starting. Specified pressure: 2.0 kg/cm² (28 psi).

Pressure builds up

No pressure

Engine floods due to defective cold start device**Possible troubles:**

- Cold start valve leaking
- Thermoswitch not switching off at higher temperatures

Wrong combination of thermostats and control unit (see list of equipment in workshop manual)

No trouble

Trouble corrected, engine starts

Pump control defective

Switch ignition on several times; pump relay should operate audibly (clicking). Switch off again after about 1 second.

Relay works

Relay does not work

Note

Following defects may be found despite visible sparking at spark plug connectors:

- Distributor cap (damp, cracked, burnt by tracking)
- Rotor defective
- Loose connections on coil
- Spark plugs or connectors defective
- Ignition timing incorrect (breaker points)
- Ignition cables poorly connected
- Arcing at ignition cables on distributor (through the rubber caps)
- Voltage at terminal 15 on coil too low (minimum = 9 volts)
- Condenser defective



Check cold start valve for sealing

Note

- Detach cold start valve from intake air distributor but leave it connected to ring main.
- Switch ignition on and off several times and check if fuel is delivered.

Note

Thermostich should not show any continuity above specified cut-in temperature.

Cut-in temperatures are:

- 311 906 161 = -12 to -18°C (10 to 0°F) (Aug. 67 to July 69)
- 311 906 161A = 0 to +10°C (32 to 14°F) (Aug. 69 to March 70)
- 311 906 161C = -6 to -14°C (21 to 7°F) (from April 70)
- 311 906 161B = -2 to -8°C (28 to 18°F) (Service use only up to March 70)

**Engine does not start****Test conditions:**

- Correct starting procedure.
- Fuel in tank.
- Starter is turning fast enough (battery voltage).

Faults in ignition system

Check ignition system and eliminate any defects.

Caution

Sparks at the plug connectors do not always indicate that ignition system is in order.

Engine does not start

Engine starts

Faults in fuel system

Check pressure in ring main with pressure gauge while starting. Specified pressure: 2.0 kg/cm² (28 psi).

Pressure builds up

No pressure

Engine floods due to defective cold start device**Possible troubles:**

- Cold start valve leaking
- Thermostich not switching off at higher temperatures

Wrong combination of thermostich and control unit (see list of equipment in workshop manual)

No trouble

Trouble corrected, engine starts

Pump control defective

Switch ignition on several times; pump relay should operate audibly (clicking). Switch off again after about 1 second.

Relay works

Relay does not work

Starting trouble

Idling trouble

Hesitation trouble


Low output/low speed too low

Fuel consumption too high

Engine misfiring

CO value too high

Wiring diagram



without deflector plate

with deflector plate

Note

On older vehicles the distributor trigger contacts with oil deflector can be service installed:


Introduced in production: July 1971

- Type 3 from Chassis No. 311 2 252 242
- Type 4 from Chassis No. 411 2 059 500

Engine does not start (cont'd from page 5)

Trouble in electrical part of injection system	
Connect tester VW 1218 and run through test program.	
No trouble	Trouble located and corrected

Clean or replace trigger contacts in distributor.



without deflector plate

with deflector plate

Note

On older vehicles the distributor trigger contacts with oil deflector can be service installed:

Introduced in production: July 1971

- Type 3 from Chassis No. 311 2252-242
- Type 4 from Chassis No. 411 2059-500

Engine does not start (cont'd from page 5)

Trouble in electrical part of injection system	
Connect tester VW 1218 and run through test program.	
No trouble	Trouble located and corrected

Clean or replace trigger contacts in distributor.

Starting trouble

Idling trouble

Hesitation trouble

Low output / top speed too low



Fuel consumption too high

Engine misfiring

CO value too high

Wiring diagram

Engine does not start (cont'd from page 5)



No voltage at fuel pump	
Switch ignition on several times and check voltage at fuel pump connection	
Voltage present	No voltage

Fuel pump defective	
Repair pump connection or replace pump	
Operate starter	
Engine does not start, no pressure in ring main	Engine starts



Fuel line blocked
Possible trouble:
 ● Fuel filter blocked
 ● Tank strainer blocked
 ● Rust in fuel tank
 Correct trouble

Pump relay defective	
Switch ignition on several times and measure voltage at terminal 87 on relay.	
Voltage present	No voltage

Possible trouble:
 ● Wire between terminal 87 of pump relay and pump defective.
 ● Pump ground wire defective
 Correct trouble

Possible causes:
 ● Fuse blown
 ● Relay defective
 Correct trouble

Engine does not start. (cont'd from page 5)



No voltage at fuel pump	
Switch ignition on several times and check voltage at fuel pump connection	
Voltage present	No voltage

Fuel pump defective	
Repair pump connection or replace pump	
Operate starter	
Engine does not start; no pressure in ring main	Engine starts

Fuel line blocked
Possible trouble:
● Fuel filter blocked
● Tank strainer blocked
● Rust in fuel tank
Correct trouble

Pump relay defective	
Switch ignition on several times and measure voltage at terminal 87 on relay.	
Voltage present	No voltage

Possible trouble:
● Wire between terminal 87 of pump relay and pump defective.
● Pump ground wire defective
Correct trouble

Possible causes:
● Fuse blown
● Relay defective
Correct trouble

Starting trouble

Idling trouble

Hesitation trouble

Low output / low speed too low

Fuel consumption too high



Engine misfiring

CD valve too high

Wiring diagram

Note

- The voltage supply relay is located as follows:
- Type 3 Sedan: on left under rear seat
 - Type 3 Squareback: on left under rear seat
 - Type 4 Four door Sedan: on left of engine compartment
 - Type 4 Wagon: on control unit



Pump relay not receiving voltage from voltage supply relay

Switch ignition on several times and check that voltage supply relay clicks.

Relay works	Relay does not work
-------------	---------------------

Faulty contact in voltage supply relay

Check voltage at voltage supply relay terminal 87 and pump relay terminal 86.

Voltage present	No voltage
-----------------	------------

Pump relay not grounded via wire 19 of control unit

Connect VW 1218 tester and run through test program

Possible trouble

- Wire 18 between control unit and starter terminal 50 defective.
- No continuity at multi-pin connector
- Control unit defective
- Trigger contacts defective

Correct trouble

Possible trouble


- Wire between voltage supply relay terminal 86 and terminal 15 in fuse box defective
 - Ground wire between terminal 85 and body or engine defective.
 - Voltage supply relay defective.
- Repair wiring or replace voltage supply relay

Possible trouble

- Wire between battery plus and terminal 30/5 of voltage supply relay defective.
 - Voltage supply relay defective.
- Correct trouble

Engine does not start (cont'd from page 5)

Note
 The voltage supply relay is located as follows:
 ● Type 3 Sedan: on left under rear seat
 ● Type 3 Squareback: on left under rear seat
 ● Type 4 Four door Sedan: on left of engine compartment
 ● Type 4 Wagon: on control unit



Pump relay not receiving voltage from voltage supply relay

Switch ignition on several times and check that voltage supply relay clicks.

Relay works	Relay does not work
-------------	---------------------

Faulty contact in voltage supply relay

Check voltage at voltage supply relay terminal 87 and pump relay terminal 86.

Voltage present	No voltage
-----------------	------------

Pump relay not grounded via wire 19 of control unit

Connect VW 1218 tester and run through test program

Possible trouble

- Wire 18 between control unit and starter terminal 50 defective.
- No continuity at multi-pin connector
- Control unit defective
- Trigger contacts defective

Correct trouble

Possible trouble

- Wire between voltage supply relay terminal 86 and terminal 15 in fuse box defective
- Ground wire between terminal 85 and body or engine defective.
- Voltage supply relay defective.

Repair wiring or replace voltage supply relay

Possible trouble

- Wire between battery plus and terminal 30/5 of voltage supply relay defective.
- Voltage supply relay defective.

Correct trouble

Starting trouble

Idling trouble

Hesitation trouble

over output/ up speed too low

Fuel consumption too high


Engine misfiring

CO value too high

Wiring diagram

Starting engine

- Gear shift lever in neutral
- Do not press accelerator pedal
This holds true for a cold engine and an engine at operating temperature no matter what the outside temperature is
- Switch on ignition and start engine
- At outside temperatures below 0°C (32°F) press clutch pedal before starting.



Cold engine does not start

Test condition:

- Fuel in tank

Incorrect starting procedure

Try to start engine using correct procedure
(in condition complaint was made)

Engine does not start or
is difficult to start

Engine starts normally

Battery voltage too low

Check state of battery charge; charge if necessary
or replace battery
Try to start engine again.

Engine does not start or
is difficult to start

Engine starts normally

Voltage at coil terminal 15 too low

Install additional wire from terminal 1 to ground.
Measure voltage at terminal 15 with voltmeter
while starter is operating.

Voltage is 9 volts
or more

Voltage is less than
9 volts


Advise customer on correct starting
procedure

Possible trouble

- Voltage drop in circuit from battery via light switch, ignition-starter switch to coil terminal 15.
- Poor ground connection between battery and body and between transmission and body.
- Starter current draw too high.
Correct trouble

Starting engine

- Gear shift lever in neutral
 - Do not press accelerator pedal
- This holds true for a cold engine and an engine at operating temperature no matter what the outside temperature is
- Switch on ignition and start engine
 - At outside temperatures below 0°C (32°F) press clutch pedal before starting.



Cold engine does not start

Test condition:

- Fuel in tank

Incorrect starting procedure

Try to start engine using correct procedure
(in condition complaint was made)

Engine does not start or
is difficult to start

Engine starts normally

Battery voltage too low

Check state of battery charge; charge if necessary
or replace battery
Try to start engine again.

Engine does not start or
is difficult to start

Engine starts normally

Voltage at coil terminal 15 too low

Install additional wire from terminal 1 to ground.
Measure voltage at terminal 15 with voltmeter
while starter is operating.

Voltage is 9 volts
or more

Voltage is less than
9 volts

Advise customer on correct starting
procedure

Possible trouble

- Voltage drop in circuit from battery via light switch, ignition-starter switch to coil terminal 15.
- Poor ground connection between battery and body and between transmission and body.
- Starter current draw too high.
Correct trouble

Starting
trouble

Idling
trouble

Hesitation
trouble

low output/
top speed
too low

Fuel consumption
too high

Engine
stalling

Oil valve
too high

Wiring
diagram



Test instructions:

Cold start valve and wiring:


- Detach cold start valve from intake air distributor but leave it connected to the ring main.
- Pull connector off thermostat and connect to ground.
- Pull wire off terminal 1 on coil
- Operate starter briefly and check if cold start valve injects fuel (catch fuel with rag).

Warning
Fire hazard

Thermostich can only be tested at very low ambient temperatures or when switch has been cooled down to actuating temperature in a refrigerator.

Actuating temperatures:

- 311 905 161 = -12 to -18°C (10 to 0°F) (Aug. 67 to July 69)
- 311 905 161A = 0 to +10°C (32 to 14°F) (Aug. 69 to March 70)
- 311 905 161C = -6 to -14°C (21 to 7°F) (from April 70)
- 311 905 161B = -2 to -8°C (28 to 18°F) (For service installation only up to March 70)



Cold engine does not start (cont'd from page 13)

Trouble in cold start device

Possible trouble:

- Cold start valve wire detached from terminal 50 of solenoid.
- Wire detached from thermostat.
- Incorrect combination of thermostat and control unit. (see list of equipment in workshop manual)
- Cold start valve or thermostat defective. Replace cold start valve or thermostat as required.

No trouble

Trouble found and corrected

Trouble in electrical part of injection system

Connect VW 121B tester and run through test program.

Possible trouble:

- Control unit defective
- Temperature sensors I and II defective
- Pressure sensor defective
- Trigger contacts defective

Correct trouble

**Test instructions:****Cold start valve and wiring:**


- Detach cold start valve from intake air distributor but leave it connected to the ring main.
- Pull connector off thermostat and connect to ground.
- Pull wire off terminal 1 on coil
- Operate starter briefly and check if cold start valve injects fuel (catch fuel with rag).

Warning
Fire hazard

Thermostwitch can only be tested at very low ambient temperatures or when switch has been cooled down to actuating temperature in a refrigerator.

Actuating temperatures:

- 311 906 161 = -12 to -18°C (10 to 0°F)
(Aug. 67 to July 69)
- 311 906 161A = 0 to +10°C (32 to 14°F)
(Aug. 69 to March 70)
- 311 906 161C = -6 to -14°C (21 to 7°F)
(from April 70)
- 311 906 161B = -2 to -8°C (28 to 18°F)
(For service installation only up to March 70)

**Trouble in cold start device****Possible trouble:**

- Cold start valve wire detached from terminal 50 of solenoid.
 - Wire detached from thermostat.
 - Incorrect combination of thermostat and control unit. (see list of equipment in workshop manual)
 - Cold start valve or thermostat defective.
- Replace cold start valve or thermostat as required.

No trouble

Trouble found and corrected

Trouble in electrical part of injection system

Connect VW 1218 tester and run through test program.

Possible trouble:

- Control unit defective
 - Temperature sensors I and II defective
 - Pressure sensor defective
 - Trigger contacts defective
- Correct trouble

Starting trouble

Idling trouble

Hesitation trouble

Poor output/
low speed
too lowFuel consumption
too high

Engine misfiring

CO value
too highWiring
diagram

Starting engine

- Gear shift lever in neutral
- Do **not** press accelerator pedal
This holds true for a cold engine and an engine at operating temperature no matter what the outside temperature is
- Switch on ignition and start engine
- At outside temperature below 0°C (32°F) press clutch pedal before starting

Cold engine does not start

Test conditions:

- Correct starting procedure being used
- Fuel in tank

Valve clearance incorrect

Adjust valves properly with **engine cold**.
Warm engine up and carry out starting tests.

Engine difficult
to start

Engine starts
normally

Pressure in ring main too high (mixture too rich)

Check pressure with gauge while operating starter
and set to 2 kg/cm² (28 psi) if necessary.
Try to start engine again.

Engine difficult
to start

Engine starts
normally

Control unit or pressure sensor making mixture too rich

Connect tester 1218 and run through test
program.
Correct trouble and try to start engine.

Engine difficult
to start

Engine starts
normally

Starting engine

- Gear shift lever in neutral
- Do not press accelerator pedal
- This holds true for a cold engine and an engine at operating temperature no matter what the outside temperature is
- Switch on ignition and start engine
- At outside temperature below 0°C (32°F) press clutch pedal before starting

Cold engine does not start

Test conditions:

- Correct starting procedure being used
- Fuel in tank

Valve clearance incorrect

Adjust valves properly with engine cold.
Warm engine up and carry out starting tests.

Engine difficult
to start

Engine starts
normally

Pressure in ring main too high (mixture too rich)

Check pressure with gauge while operating starter
and set to 2 kg/cm² (20 psi) if necessary.
Try to start engine again.

Engine difficult
to start

Engine starts
normally

Control unit or pressure sensor making mixture too rich

Connect tester 1218 and run through test
program.
Correct trouble and try to start engine.

Engine difficult
to start

Engine starts
normally

Starting
trouble

Idling
trouble

Hesitation
trouble

Low output/
top speed
too low



Fuel con-
sumption
too high

Engine
misfiring

CO value
too high

Wiring
diagram

Hot engine does not start (cont'd from page 17)



Note
The thermoswitch should not show any continuity above the specified switch-on temperature.

Actuating temperatures:

- 311 906 161 = -12 to -18°C (10 to 0°F)
(Aug. 67 to July 69)
- 311 906 161A = 0 to +10°C (32 to 14°F)
(Aug. 69 to March 70)
- 311 906 161C = -6 to -14°C (21 to 7°F)
(from April 70)
- 311 906 161B = -2 to -8°C (28 to 18°F)
(For service installation only up to March 70)

Resistances of temperature sensors I + II too high despite OK indication (mixture too rich).

Remove temperature sensors. Let them cool down to room temperature and measure resistance with ohmmeter:

- Sensor I not more than 300 Ω
- Sensor II not more than 2.5 k Ω

Replace defective sensors and try to start engine again.

Engine difficult to start

Engine starts normally

Engine floods due to defective cold start device

Possible trouble:

- Cold start valve leaking
- Thermoswitch does not switch off at higher temperatures

Correct trouble, try to start engine again.

Engine difficult to start

Engine starts normally

Injectors leaking



Remove injectors but leave them connected to the ring main.

Switch ignition on and off several times without starting engine

Warning Fire hazard

Have second mechanic check if more than two drops are ejected by each injector per minute.

Replace leaking injectors.



Note
The thermostat should not show any continuity above the specified switch-on temperature.

Actuating temperatures:

- 311 906 161 = -12 to -18°C (10 to 0°F)
(Aug. 67 to July 69)
- 311 906 161A = 0 to +10°C (32 to 14°F)
(Aug. 69 to March 70)
- 311 906 161C = -6 to -14°C (21 to 7°F)
(from April 70)
- 311 906 161B = -2 to -8°C (28 to 18°F)
(For service installation only up to March 70)

Hot engine does not start (cont'd from page 17)

Resistances of temperature sensors I + II too high despite OK indication (mixture too rich).

Remove temperature sensors. Let them cool down to room temperature and measure resistance with ohmmeter:

- Sensor I not more than 300 Ω
- Sensor II not more than 2.5 kΩ

Replace defective sensors and try to start engine again.

Engine difficult to start

Engine starts normally

Engine floods due to defective cold start device

Possible trouble:

- Cold start valve leaking
- Thermostat does not switch off at higher temperatures

Correct trouble, try to start engine again.

Engine difficult to start

Engine starts normally

Injectors leaking

Remove injectors but leave them connected to the ring main.

Switch ignition on and off several times without starting engine

Warning Fire hazard

Have second mechanic check if more than two drops are ejected by each injector per minute.

Replace leaking injectors.

Starting trouble

Idling trouble

Hesitation trouble

over output/
top speed too low






Fuel consumption too high

Engine mistfiring

CO value too high

Wiring diagram

Engine starts but stops again after a short time



Engine starts but stops again after a short time

Starting trouble

Idling trouble

Hesitation trouble

Low output/
low speed
too low

Fuel consumption
too high

Engine misfiring

CO value
too high


Wiring
diagram

Trouble in electrical part of injection system	
Connect tester VW 1218 and run through test program	
Possible trouble:	
<ul style="list-style-type: none"> ● Control unit defective ● Temperature sensor II (cylinder head) defective ● Pressure sensor defective 	
No trouble	Trouble corrected

Temperature sensor II defective despite OK indication	
Remove sensor, let it cool down to room temperature and measure resistance with an ohmmeter.	
Specified value: 1.5 to 2.5 k Ω	
Resistance clearly too high	Resistance OK

Auxiliary air regulator defective
Check air flow through regulator with engine cold If there is no flow or a restricted flow, replace auxiliary air regulator

Replace temperature sensor II



Rough idle during warm-up

Test conditions:

- Valve clearance and ignition timing correct (very important).
- Idling speed of warm engine within specified tolerances.
- Let engine cool down to ambient temperature before starting test.

Idle enrichment inadequate during the warm-up phase

Start engine.
When auxiliary air regulator has closed (after 3-4 minutes), measure idle variation.

Variation more than 100 rpm

Variation less than 100 rpm

Type 3
Type 4

Idling CO potentiometer setting too lean

Turn potentiometer slowly clockwise until idle is normal (Variation less than 100 rpm)

Idle OK

Idle still varying

Check that CO is not too high when engine is warm (50-70°C/122-158°F)
If the CO is considerably above the permissible maximum, look for fault in "CO value too high" section of guide

This variation is permissible and requires no repair work

Idle contact in throttle valve switch not in order

Possible trouble:

- Throttle valve switch incorrectly adjusted
- Wire 17 between throttle valve switch and control unit defective
- Throttle valve switch defective

Rough Idle during warm-up

Test conditions:

- Valve clearance and ignition timing correct (very important).
- Idling speed of warm engine within specified tolerances.
- Let engine cool down to ambient temperature before starting test.

Idle enrichment inadequate during the warm-up phase

Start engine.
When auxiliary air regulator has closed (after 3-4 minutes), measure idle variation.

Variation more than 100 rpm

Variation less than 100 rpm

Type 4
Type 3

Idling CO potentiometer setting too lean

Turn potentiometer slowly clockwise until idle is normal (Variation less than 100 rpm)

idle OK

Idle still varying

Check that CO is not too high when engine is warm (50-70°C/122-158°F)
If the CO is considerably above the permissible maximum, look for fault in "CO value too high" section of guide

This variation is permissible and requires no repair work

Idle contact in throttle valve switch not in order

Possible trouble:

- Throttle valve switch incorrectly adjusted
- Wire 17 between throttle valve switch and control unit defective
- Throttle valve switch defective

Rough idle during warm-up

Test conditions:

- Valve clearance and ignition timing correct (very important).
- Idling speed of warm engine within specified tolerances.
- Let engine cool down to ambient temperature before starting test.

Idle enrichment inadequate during the warm-up phase

Start engine.
When auxiliary air regulator has closed (after 3-4 minutes), measure idle variation.

Variation more than 100 rpm

Variation less than 100 rpm

Type 3
Type 4

Idling CO potentiometer setting too lean

Turn potentiometer slowly clockwise until idle is normal (Variation less than 100 rpm)

Idle OK

Idle still varying

Check that CO is not too high when engine is warm (50-70°C/122-158°F)
If the CO is considerably above the permissible maximum, look for fault in "CO value too high" section of guide

This variation is permissible and requires no repair work

Idle contact in throttle valve switch not in order

Possible trouble:

- Throttle valve switch incorrectly adjusted
- Wire 17 between throttle valve switch and control unit defective
- Throttle valve switch defective

Idling trouble

Hesitation trouble

oor output/
top speed too low

Fuel consumption too high

Engine misfiring

CO value too high

Wiring diagram

Hunting at idle at all temperatures




Note

This point concerns only vehicles with deceleration fuel cutoff

- Type 3 up to Chassis No. 311 2500 000
- Type 4 up to Chassis No. 411 2100 000

Test condition:

- Engine warm (50–70°C/122–158°F)
- Engine running at idle



Replace regulator

Pull intake elbow off throttle valve support, close off by-pass drilling with thumb and listen for sucking noises.

Possible causes for leaks:

- Hoses between intake manifolds and intake air distributor
- Intake manifold gaskets
- Rubber mountings for injectors
- Vacuum hoses

Eliminate all leaks found

Check wire to terminal 87 on pump relay and repair.

Hunting at idle at all temperatures



Note

This point concerns only vehicles with deceleration fuel cutoff

- Type 3 up to Chassis No. 3112500000
- Type 4 up to Chassis No. 4112100000

Test condition:

- Engine warm (50–70°C/122–158°F)
- Engine running at idle



Idling trouble

Hesitation trouble

poor output/
top speed too low

Fuel consumption too high

Engine misfiring

CO value too high

Wiring diagram

Hot engine stalls at idle

Test condition
● Engine cold

Valve clearance incorrect

Check clearance and – if necessary – set exactly (very important).
Warm up engine and check if it will idle properly

Engine stalls

Engine idles properly

Trouble in electrical part of injection system

Connect tester 1218 and run through the guide

Possible trouble:

- Throttle valve switch incorrectly adjusted
- Control unit defective
- Pressure sensor defective (too lean)

Correct trouble

Hot engine stalls at idle

Test condition
● Engine cold

Valve clearance incorrect

Check clearance and – if necessary – set exactly (very important).
Warm up engine and check if it will idle properly

Engine stalls

Engine idles properly

Trouble in electrical part of injection system

Connect tester 1218 and run through the guide

Possible trouble:

- Throttle valve switch incorrectly adjusted
- Control unit defective
- Pressure sensor defective (too lean)

Correct trouble

Idling trouble

Hesitation trouble


Low output/
top speed too low

Fuel consumption too high

Engine misfiring

CO value too high

Wiring diagram



Idling speed regulator
(only Type 4/Automatic Transm.)

Note

Engine oil temperature must be 50–70°C (122–158°F).

Regulator must be adjusted with engine running.

Adjustment

1 – Set idle to 850–900 rpm.

2 – Apply parking brake and select driving range.

In this condition idle should be approximately 800–700 rpm. Play at "a" should be 0.5–1.0 mm (0.02–0.04 in.)

3 – Adjust play as required on M 5 screw (arrow).

Uneven idle in driving range (Automatic Type 4)

Test conditions:

- No variation in idle with lever at "N"
- Idle speed with engine warm 850–900 rpm

Idling speed regulator incorrectly adjusted


Check adjustment and correct if necessary

Idle still uneven

Idle OK

Install regulator with softer spring.

Production: From Engine No.
W 0105 249



Temperature must be 50–70°C (122–158°F).

must be adjusted with engine running.

at

to 850–900 rpm.

arking brake and select driving range.



condition idle should be
nately 600–700 rpm. Play at "a" should
1.0 mm (0.02–0.04 in.)

lay as required on M 5 screw (arrow).

Uneven idle in driving range (Automatic Type 4)

Test conditions:

- No variation in idle with lever at "N"
- Idle speed with engine warm 850–900 rpm



Idling speed regulator
(only Type 4/Automatic Trans.)

Idling
trouble

Hesitation
trouble


oor output/
top speed
too low

Fuel con-
sumption
too high

Engine
misfiring

CO value
too high

Wiring
diagram



- 1 - Pressure sensor connector
- 2 - Connector for temperature sensor II
- 3 - Connectors for injectors.

Note

The area near the plug connector for No. 3 cylinder on the Type 4/Wagon is particularly critical.

Repair instructions:

- a - Pull wires off pressure sensor, temperature sensor II (cylinder head) and injectors for cylinders 3 and 4.
- b - Route wiring behind fuel line on pressure regulator (see illustration).
- c - Connect wires again.

Idle irregular (like misfiring)

Test conditions:


- Engine warm (50°-70° C/122-158° F)
- Engine running at idling speed

Inductance from ignition system	
Check if the injection system wiring is coming into contact with the high tension ignition cables (see instructions on left)	
Route wiring so that it is as far as possible from ignition cables	
Idle still irregular	Idle OK

Trouble occurs only when heater is switched on	
Switch heater off and watch idle	
Idle still irregular	Idle OK when heater is switched off

Inductance from some other source	
Possible trouble:	
<ul style="list-style-type: none"> ● Powerful radio station in immediate vicinity ● Two-way radio on vehicle near engine 	
No remedy normally required	

Trouble in heater electrical system	
Possible cause:	
<ul style="list-style-type: none"> ● Defective condenser in combustion air blower 	
Replace combustion air blower.	



Pressure sensor connector
 Connector for temperature sensor II
 Connectors for injectors.

Note

The area near the plug connector for No. 3 cylinder on the Type 4/Wagon is particularly critical.

Repair instructions:

- a - Pull wires off pressure sensor, temperature sensor II (cylinder head) and injectors for cylinders 3 and 4
- b - Route wiring behind fuel line on pressure regulator (see illustration).
- c - Connect wires again.

Idle irregular (like misfiring)

Test conditions:

- Engine warm (50°-70°C/122-158°F)
- Engine running at idling speed

Inductance from ignition system	
Check if the injection system wiring is coming into contact with the high tension ignition cables (see instructions on left)	
Route wiring so that it is as far as possible from ignition cables	
Idle still irregular	Idle OK

Trouble occurs only when heater is switched on	
Switch heater off and watch idle	
Idle still irregular	Idle OK when heater is switched off

Inductance from some other source	
Possible trouble:	
<ul style="list-style-type: none"> ● Powerful radio station in immediate vicinity ● Two-way radio on vehicle near engine 	
No remedy normally required	

Trouble in heater electrical system	
Possible cause:	
<ul style="list-style-type: none"> ● Defective condenser in combustion air blower Replace combustion air blower.	

Idling trouble

Hesitation trouble

Poor output/ top speed too low

Fuel consumption too high

Engine misfiring

CD value too high

Wiring diagram

Idle too high

Test conditions:

- Engine warm (50–70°C/122–158°F)
- Tachometer connected
- Engine running at idle

Throttle valve not closing

Press throttle valve with thumb to see if it is fully closed and watch idle

Idle does not drop

Idle drops

Adjusting screw out of adjustment

Adjust idle by turning screw

Idle cannot be set properly

Idle can be adjusted

Auxiliary air regulator not closing

Pull regulator hose off at intake elbow and seal with thumb.

Idle does not drop

Idle drops

Pull intake elbow off throttle valve connection. Close idling by-pass drilling with thumb and listen for suction noises.

Possible sources of leakage:


- Hoses between intake pipes and intake air distributor
 - Intake pipe gaskets on cylinder head
 - Rubber mountings for injectors
 - Vacuum hoses
 - Crankcase ventilation valve or hose to intake air distributor defective
- Eliminate any leaks.

Throttle valve sticking

Possible trouble:

- Throttle controls stiff (accelerator cable or pedal)
- Throttle shaft stiff in operation
- Throttle valve switch incorrectly adjusted
- Throttle valve switch base plate bent







Correct trouble




Idle too high


Test conditions:

- Engine warm (50–70°C/122–158° F)
- Tachometer connected
- Engine running at idle



- Idling trouble
- Hesitation trouble
- Poor output/top speed too low
- Fuel consumption too high
- Engine misfiring
- CO value too high
- Wiring diagram





Idling trouble

Hesitation trouble

Poor output/
top speed too low

Fuel consumption too high

Engine misfiring

CO value too high

Wiring diagram

Hesitation trouble

Test condition:

- Vehicle reaches maximum speed
(otherwise see "Poor output")

Acceleration enrichment ineffective	
Switch ignition on and open throttle slowly by hand.	
Listen whether injectors click (20 times)	
Clicking heard	No clicking heard

Trouble in electrical part of injection system	
Connect tester VW 121B and run through test program	
Correct any trouble found and road test vehicle	
Progression still not satisfactory	Performance on road test OK

Mechanical trouble in pressure sensor	
Check by using a new pressure sensor and road test vehicle again.	
Progression still not satisfactory	Performance on road test OK

Wires on throttle valve switch faulty or switch defective

Check wiring connections and repair as necessary, otherwise replace switch.

Hesitation trouble

Test condition:

- Vehicle reaches maximum speed (otherwise see "Poor output")

Acceleration enrichment ineffective	
Switch ignition on and open throttle slowly by hand.	
Listen whether injectors click (20 times)	
Clicking heard	No clicking heard

Trouble in electrical part of injection system	
Connect tester VW 1218 and run through test program	
Correct any trouble found and road test vehicle	
Progression still not satisfactory	Performance on road test OK

Mechanical trouble in pressure sensor	
Check by using a new pressure sensor and road test vehicle again.	
Progression still not satisfactory	Performance on road test OK

Wifes on throttle valve switch faulty or switch defective
Check wiring connections and repair as necessary, otherwise replace switch.

Hesitation trouble


Poor output/
top speed too low

Fuel consumption too high

Engine misfiring

CO value too high

Wiring diagram



Hesitation trouble (cont'd from page 39)

Incorrect matching of control unit and temperature sensor (mixture too weak)

Check matching

The service temperature sensors I (311 906 081 B) and II (022 906 041 A) must not be installed in vehicles which have control units with yellow, brown or black stickers

Parts match

Parts do not match


Defect in ignition system

Possible trouble:

- Contact breaker
- Ignition timing
- Spark advance settings
- Spark plug gaps

Correct trouble

Install correct temperature sensor as shown in list of equipment in workshop manual.



Incorrect matching of control unit and temperature sensor (mixture too weak)

Check matching

The service temperature sensors I (311 906 081 B) and II (022 906 041 A) must not be installed in vehicles which have control units with yellow, brown or black stickers

Parts match

Parts do not match

Defect in ignition system

Possible trouble:

- Contact breaker
 - Ignition timing
 - Spark advance settings
 - Spark plug gaps
- Correct trouble

Install correct temperature sensor as shown in list of equipment in workshop manual.

Hesitation trouble

poor output/
top speed
too low

Fuel consumption
too high

Engine
misfiring

CO value
too high

Wiring
diagram

Road testing instructions:

- Increase tire pressures to 3 psi above normal tire pressure
- Engine and transmission must be warm
- Level, dry asphalt road surface
- Normal wind conditions
- Take average readings from one run in each direction
- Check maximum speed where legally permitted on a measured test stretch (1 mile) with a stop watch
- Find actual speed from table below and compare with speedometer to find variation

Speed table
— for 1 mile stretch

Seconds	mph
58	62
55	65
52	69
48	75
45	80
43	85
40	90
38	95
36	100

Possible trouble in ignition system:

- Distributor cap (damp, cracked, burnt by tracking)
- Rotor defective
- Ignition timing incorrect (breaker points)
- Condenser defective
- Loose connections on coil
- Ignition cables poorly connected
- Spark plugs or connectors defective
- Centrifugal spark control defective
- Arcing at ignition cables on distributor (through protective caps)

Poor output / top speed too low

Test conditions:

- Speedometer reading normal (see instructions on left)
- Tire size and type equivalent to standard
- Wheels turning freely (brakes, bearings)

Faulty engine adjustment**Procedure:**

- Check valve clearance with engine cold and adjust if necessary
- Check accelerator cable adjustment. (Throttle must be fully open with pedal at full throttle).
- On Type 4 up to model year 71:
Check that crankcase ventilation control flap moves freely.
- Check ignition timing and adjust if necessary.

No trouble

Trouble corrected

Troubles in ignition system

Check ignition system and eliminate any faults found.

Caution

Visible sparks do not always prove that the ignition system is in order (see remarks on left).

No trouble

Trouble corrected

Road test

Output poor

Output O.K.

Road test

Output poor

Output O.K.

Road testing instructions:

- Increase tire pressures to 3 psi above normal tire pressure
- Engine and transmission must be warm
- Level, dry asphalt road surface
- Normal wind conditions
- Take average readings from one run in each direction
- Check maximum speed where legally permitted on a measured test stretch (1 mile) with a stop watch
- Find actual speed from table below and compare with speedometer to find variation

Speed table
— for 1 mile stretch

Seconds	mph
58	62
55	65
52	69
48	75
45	80
43	85
40	90
38	95
36	100

Possible trouble in ignition system:

- Distributor cap (damp, cracked, burnt by tracking)
- Rotor defective
- Ignition timing incorrect (breaker points)
- Condenser defective
- Loose connections on coil
- Ignition cables poorly connected
- Spark plugs or connectors defective
- Centrifugal spark control defective
- Arcing at ignition cables on distributor (through protective caps)

Poor output / top speed too low**Test conditions:**

- Speedometer reading normal (see instructions on left)
- Tire size and type equivalent to standard
- Wheels turning freely (brakes, bearings)

Faulty engine adjustment**Procedure:**

- Check valve clearance with engine cold and adjust if necessary
- Check accelerator cable adjustment. (Throttle must be fully open with pedal at full throttle).
- On Type 4 up to model year 71: Check that crankcase ventilation control flap moves freely.
- Check ignition timing and adjust if necessary.

No trouble

Trouble corrected

Troubles in ignition system

Check ignition system and eliminate any faults found.

Caution

Visible sparks do not always prove that the ignition system is in order (see remarks on left).

No trouble

Trouble corrected

Road test

Output poor

Output O.K.

Road test

Output poor

Output O.K.


Poor output/
top speed
too low

Fuel consumption
too high

Engine
misfiring

CD value
too high

Wiring
diagram





without deflector plate

with deflector plate

Note
 On older vehicles the distributor trigger contacts with oil deflector can be service installed.
 Introduced in production: July 1971
 ● Type 3 from Chassis No. 311 2252 242
 ● Type 4 from Chassis No. 411 2059 500

Poor output / Top speed too low (cont'd from page 43)





without deflector plate

with deflector plate


Note

On older vehicles the distributor trigger contacts with oil deflector can be service installed.

Introduced in production: July 1971

- Type 3 from Chassis No. 311 2252 242
- Type 4 from Chassis No. 411 2059 500

Poor output / Top speed too low (cont'd from page 43)



Poor output/
top speed
too low

Fuel consumption
too high

Engine
misfiring

CO value
too high

Wiring
diagram

Fuel pressure in ring main too low at full throttle

Measure pressure with gauge:
at idle and
at full throttle (on test stand or on road test
with extended gauge connections)

Pressure at idle at full throttle approx. 2 kg/cm ² (28 psi)	Pressure drops noticeably at full throttle	Pressure at idle and full throttle the same but too low
---	--	---

Wheel toe badly out of adjustment
causing increased roll resistance

Check front and rear wheel
toe and adjust if necessary

Toe OK	Toe not OK Adjust toe
--------	--------------------------

Transmission or final drive
binding

Defect is usually accompanied
by excessive noise (droning,
grinding etc.) and/or by
excessive heat development.

Not enough fuel delivered






Possible causes:

- Fuel filter blocked
- Strainer in tank blocked
- Rust in fuel tank
- Pump not delivering sufficient fuel

Correct trouble

Pressure regulator incorrectly
adjusted
Adjust pressure to 2 kg/cm²
(28 psi)

Note
Abnormal tire wear can indicate
wrong toe adjustment



Note
Abnormal tire wear can indicate
wrong toe adjustment

Poor output/
top speed
too low

Fuel con-
sumption
too high

Engine
misfiring

CO value
too high


Wiring
diagram

Road testing instructions:

- Where possible customer should be present during road test
- Plan test route to include mixed driving and traffic conditions (equal parts of city traffic, open road and expressway)
- Do **not** switch heater on during the test
- Measure consumption with a fuel consumption tester or by filling fuel tank exactly before and after test
- Approximate consumption figures for mixed traffic at an ambient temperature above 0°C (32° F) are:
 - Type 3 / Manual approx. 18.7 mpg/US or 23 mpg/Imp.
 - Type 3 / Automatic approx. 17.6 mpg/US or 21.5 mpg/Imp.
 - Type 4 / Manual approx. 17 mpg/US or 20 mpg/Imp.
 - Type 4 / Automatic approx. 16.2 mpg/US or 19.9 mpg/Imp.

Caution

- These figures are only for comparison with figure obtained during road test under given driving and traffic conditions. They are not to be used for comparison with consumption figures given by customer.
- When vehicle is driven short distances in rush hours conditions, consumption can go up to 20 liters for 100 km (11.3 mpg/US or 13.4 mpg/Imp. for 60 miles)
- When discussing fuel consumption, remember that the heater (Type 4) also uses from 0.5 to 3 liters per 100 km (1 to 6 pts/US per 60 miles or 0.8 to 4.6 pts/Imp per 60 miles)



Fuel consumption too high

Test condition:

- Standard tire size and type
- Wheels turning freely (brakes, wheel bearings)
- Ignition timing correct
- Road test has shown clearly that fuel consumption is too high (see remarks on left)

Trouble in electrical part of injection system

Connect tester VW 1218 and run through test program

No trouble

Trouble corrected

Resistances of temperature sensors too high despite OK indication (mixture too rich)

Remove temperature sensors I and II and measure resistances with ohmmeter at room temperature

- Sensor I not more than 300 Ω
- Sensor II not more than 2.5 k Ω

Resistance not too high

Resistance too high

Pressure in ring main too high

Measure pressure with gauge
Specified figure 2 kg/cm² (28 psi)

Pressure OK

Pressure well above
2 kg/cm² (28 psi)


Replace defective temperature sensor

Road testing instructions:

- Where possible customer should be present during road test
- Plan test route to include mixed driving and traffic conditions (equal parts of city traffic, open road and expressway)
- Do **not** switch heater on during the test
- Measure consumption with a fuel consumption tester or by filling fuel tank exactly before and after test
- Approximate consumption figures for mixed traffic at an ambient temperature above 0°C (32° F) are:
 - Type 3 / Manual approx.
18.7 mpg/US or 23 mpg/Imp.
 - Type 3 / Automatic approx.
17.6 mpg/US or 21.5 mpg/Imp.
 - Type 4 / Manual approx.
17 mpg/US or 20 mpg/Imp.
 - Type 4 / Automatic approx.
16.2 mpg/US or 19.9 mpg/Imp.

Caution

- These figures are only for comparison with figure obtained during road test under given driving and traffic conditions. They are not to be used for comparison with consumption figures given by customer.
- When vehicle is driven short distances in rush hours conditions, consumption can go up to 20 liters for 100 km (11.3 mpg/US or 13.4 mpg/Imp. for 60 miles)
- When discussing fuel consumption, remember that the heater (Type 4) also uses from 0.5 to 3 liters per 100 km (1 to 6 pts/US per 60 miles or 0.8 to 4.6 pts/Imp per 60 miles)



Fuel consumption too high

Test condition:

- Standard tire size and type
- Wheels turning freely (brakes, wheel bearings)
- Ignition timing correct
- Road test has shown clearly that fuel consumption is too high (see remarks on left)

Trouble in electrical part of injection system	
Connect tester VW 1218 and run through test program	
No trouble	Trouble corrected

Resistances of temperature sensors too high despite OK indication (mixture too rich)	
Remove temperature sensors I and II and measure resistances with ohmmeter at room temperature	
● Sensor I not more than 300 Ω ● Sensor II not more than 2.5 k Ω	
Resistance not too high	Resistance too high

Pressure in ring main too high	
Measure pressure with gauge	
Specified figure 2 kg/cm ² (28 psi)	
Pressure OK	Pressure well above 2 kg/cm ² (28 psi)


Replace defective temperature sensor

Fuel consumption too high

Engine misfiring

CO value too high

Wiring diagram



Note

- Detach cold start valve from intake air distributor but leave it connected to the ring main.
- Switch ignition on and off several times and check if fuel is delivered.

Fuel consumption too high (cont'd from page 49)

Cold start valve leaking

Check cold start valve for leakage

No trouble	Trouble corrected
------------	-------------------

Thermostat for cooling air regulation incorrectly adjusted or defective

Check thermostat and adjustment of cooling air regulation.

No trouble	Trouble corrected
------------	-------------------

Intake valves leaking despite correct adjustment

Check compression

Compression OK	Compression poor
----------------	------------------

Only Type 3 with pressure switch (up to July 69)

Pressure switch not opening

Run engine, pull connector off pressure switch and check switch for continuity.

No continuity	Switch has continuity
---------------	-----------------------

Repair engine


Note

Vehicles with control units which do not have a yellow, brown or black sticker that is:


- Type 3 up to Chassis No. 3112090091
- Type 4 up to Chassis No. 4112018712

can be equipped with temperature sensors 311906181 B (for Type 3) and 022906041A (for Type 4) if measures above do not fix the problem

Replace switch



Fuel consumption too high (cont'd from page 49)



Note

- Detach cold start valve from intake air distributor but leave it connected to the ring main.
- Switch ignition on and off several times and check if fuel is delivered.

Cold start valve leaking	
Check cold start valve for leakage	
No trouble	Trouble corrected

Thermostat for cooling air regulation incorrectly adjusted or defective	
Check thermostat and adjustment of cooling air regulation.	
No trouble	Trouble corrected

Intake valves leaking despite correct adjustment	
Check compression	
Compression OK	Compression poor

Only Type 3 with pressure switch (up to July 69)

Pressure switch not opening	
Run engine, pull connector off pressure switch and check switch for continuity.	
No continuity	Switch has continuity


Repair engine

Replace switch

Note
Vehicles with control units which do not have a yellow, brown or black sticker that is:

- Type 3 up to Chassis No. 3112090091
- Type 4 up to Chassis No. 4112018712

can be equipped with temperature sensors 311906181 B (for Type 3) and 022906041 A (for Type 4) if measures above do not fix the problem



Fuel consumption too high

Engine misfiring

CO value too high

Wiring diagram

Pressure regulator incorrectly adjusted

Reduce pressure in ring main to 2 kg/cm² (28 psi)

Pressure cannot be reduced

Pressure can be reduced



Possible trouble:

- Return line between pressure regulator and tank kinked or blocked
 - Pressure regulator defective
- Correct trouble

Fuel consumption too high (cont'd from page 49)

Pressure regulator incorrectly adjusted	
Reduce pressure in ring main to 2 kg/cm ² (28 psi)	
Pressure cannot be reduced	Pressure can be reduced



Possible trouble:

- Return line between pressure regulator and tank kinked or blocked
- Pressure regulator defective

Correct trouble

Fuel consumption too high

Engine misfiring


CO value too high

Wiring diagram

00-10000000-0000-0000-0000-000000000000




00-10000000-0000-0000-0000-000000000000



Engine misfiring only when electrical components are switched on.

Engine misfiring at all times



Engine misfiring only when electrical components are switched on.

Engine misfiring at all times

Engine misfiring

CO value too high

Wiring diagram

Engine misfiring only when electrical components are switched on

Trouble in voltage supply to control unit

Check if there is a direct connection between battery positive terminal and terminal 30/51 on the voltage supply relay.

Wiring direct	Wiring runs via fuse box
---------------	--------------------------

Poor ground connections

Check ground connections between battery and body, between body and transmission

Run engine and switch on all electrical components several times one after the other.

Misfiring only when heater is switched on	No misfiring
---	--------------

Pull wire to voltage supply relay off at fuse box. Connect it directly to battery positive terminal

Trouble in electrical part of heater

Possible trouble:


- Condenser in combustion air blower defective

Replace combustion air blower.

Still misfiring	No misfiring
-----------------	--------------

See "misfiring at all times"

Engine misfiring only when electrical components are switched on



Engine misfiring

CD value too high

Wiring diagram

Note
If misfiring occurs only after deceleration the engine is probably sucking in oil through the crankcase breather or valve guides (can often be recognized by blue exhaust during deceleration).

In this case check crankcase ventilation system and valve guide wear.

- Possible defects in ignition system**
- Loose connections on coil
 - Distributor cap (damp, cracked, burnt by tracking)
 - Rotor defective
 - Ignition timing incorrect (breaker points)
 - Ignition cables poorly or incorrectly connected
 - Spark plugs or connectors defective
 - Arcing at ignition cables on distributor (through the rubber caps)
 - Condenser defective
 - Injection wiring touching ignition cables

Note
When checking connections do not forget the less accessible connections such as

- Voltage supply relay
- Pump relay
- Central ground connection on crankcase
- Wire 30 to voltage supply relay on battery positive (Type 4 only)
- Multi-pin connector on control unit

Test condition:

- Check if misfiring occurs only when electrical components are switched on and off. If so, see page 57.
- Check if misfiring occurs only after deceleration. If so, see remarks on left.

Trouble in ignition system	
Check system and eliminate defects (see remarks on opposite page).	
No trouble	Trouble corrected

Faulty terminal or ground connections in the injection system	
Check all connections systematically for tight fit and corrosion. (see remarks on opposite page).	
No trouble	Trouble corrected

Parts of injection system or wiring defective	
Connect tester VW 1218 and run through test program During test stages 4 to 11, tap the control unit by hand (to detect loose soldered connections) During all other test stages, move wiring concerned to detect breaks in wires Correct trouble	
No trouble	Trouble corrected

Engine misfiring at all the times

Note

If misfiring occurs only after deceleration the engine is probably sucking in oil through the crankcase breather or valve guides (can often be recognized by blue exhaust during deceleration).

In this case check crankcase ventilation system and valve guide wear.

Possible defects in ignition system

- Loose connections on coil
- Distributor cap (damp, cracked, burnt by tracking)
- Rotor defective
- Ignition timing incorrect (breaker points)
- Ignition cables poorly or incorrectly connected
- Spark plugs or connectors defective
- Arcing at ignition cables on distributor (through the rubber caps)
- Condenser defective
- Injection wiring touching ignition cables

Note

When checking connections do not forget the less accessible connections such as

- Voltage supply relay
- Pump relay
- Central ground connection on crankcase
- Wire 30 to voltage supply relay on battery positive (Type 4 only)
- Multi-pin connector on control unit

Test condition:

- Check if misfiring occurs only when electrical components are switched on and off. If so, see page 57.
- Check if misfiring occurs only after deceleration. If so, see remarks on left.

Trouble in ignition system

Check system and eliminate defects (see remarks on opposite page).

No trouble

Trouble corrected

Faulty terminal or ground connections in the injection system

Check all connections systematically for tight fit and corrosion. (see remarks on opposite page).

No trouble

Trouble corrected

Parts of injection system or wiring defective

Connect tester VW 1218 and run through test program

During test stages 4 to 11, tap the control unit by hand (to detect loose soldered connections)

During all other test stages, move wiring concerned to detect breaks in wires

Correct trouble


No trouble

Trouble corrected

Engine misfiring

CO value too high

Wiring diagram



without deflector plate

with deflector plate




Note

On older vehicles distributor trigger contacts with oil deflector can be service installed.


Introduced in production: July 1971

- Type 3 from Chassis No. 311 2 252 242
- Type 4 from Chassis No. 411 2 059 500

Engine misfiring at all times (cont'd from page 59)



Try a different regulator, install belt again and road test vehicle. If fault still exists: Repair or replace generator/alternator



ector plate

with deflector plate





Note

On older vehicles distributor trigger contacts with oil deflector can be service installed.

Introduced in production: July 1971

- Type 3 from Chassis No. 3112252242
- Type 4 from Chassis No. 4112059500


Engine misfiring at all times (cont'd from page 59)




Engine misfiring

CO value too high

Wiring diagram



Note
The service installation of a potentiometer (311 906 019) will not eliminate the fault "CO value too high". This is intended only to improve mixture enrichment (Service remedy for hunting at idling speed).



CO value too high

Test conditions:

- Valve clearance and ignition timing correct (very important)
- Engine temperature between 50 and 70° C (122–158° F)

Idling CO potentiometer (if installed) incorrectly adjusted	
Adjust CO with potentiometer (on control unit or – if subsequently installed – in engine compartment; see arrow in illustrations)	
CO remains too high	CO can be adjusted

Pressure in ring main too high	
Check pressure with gauge. Specified figure: 2 kg/cm ² (28 psi)	
Pressure is correct	Pressure well above 2 kg/cm ² (28 psi)

Trouble in electrical part of injection system	
Connect tester VW 1218 and run through test program	
No trouble	Trouble corrected


Pressure regulator incorrectly adjusted	
Set pressure to 2 kg/cm ² (28 psi)	
Pressure cannot be adjusted	Pressure can be adjusted

Only Type 3 with pressure switch (up to July 69)

Possible trouble:


- Return line between pressure regulator and tank kinked or blocked
- Pressure regulator defective

Repair as necessary



Note

The service installation of a potentiometer (311906 019) will not eliminate the fault "CO value too high". This is intended only to improve mixture enrichment (Service remedy for hunting at idling speed).



CO value too high

Test conditions:

- Valve clearance and ignition timing correct (very important)
- Engine temperature between 50 and 70°C (122–158° F)

Idling CO potentiometer (if installed) incorrectly adjusted

Adjust CO with potentiometer (on control unit or – if subsequently installed – in engine compartment; see arrow in illustrations)

CO remains too high

CO can be adjusted

Pressure in ring main too high

Check pressure with gauge.
Specified figure: 2 kg/cm² (28 psi)

Pressure is correct

Pressure well above
2 kg/cm² (28 psi)

Trouble in electrical part of injection system

Connect tester VW 1218 and run through test program

No trouble

Trouble corrected

Pressure regulator incorrectly adjusted

Set pressure to 2 kg/cm² (28 psi)

Pressure cannot be adjusted

Pressure can be adjusted


Possible trouble:

- Return line between pressure regulator and tank kinked or blocked
- Pressure regulator defective
Repair as necessary

Only Type 3
with pressure
switch (up to
July 69)


CO value
too high

Wiring
diagram




Check vacuum pipe to pressure switch or replace pressure switch

CO value too high (cont'd from page 63)



CO value too high



Resistances of temperature sensors too high despite OK indication (mixture too rich)

Remove sensors I and II and measure resistance with an ohmmeter at room temperature (about 20°C/68°F)

- Sensor I not more than 300 Ω
- Sensor II not more than 2.5 k Ω

Resistances correct	Resistances too high
---------------------	----------------------

Injectors or cold start valve leaking

Check for leaks with injectors and cold start valve connected to ring main. Switch ignition on and off several times.

No leaks found	Leaks found and eliminated
----------------	----------------------------

Replace defective temperature sensors

Inlet valves leaking despite correct adjustment

Check compression

Compression OK	Compression poor
----------------	------------------


Repair engine

CO influenced excessively by crankcase breather

Possible causes:

- Too much oil in engine
- Oil dilution by fuel
- Pistons, rings and cylinders worn

Repair as necessary



Resistances of temperature sensors too high despite OK indication (mixture too rich)	
Remove sensors I and II and measure resistance with an ohmmeter at room temperature (about 20°C/68°F)	
<ul style="list-style-type: none"> ● Sensor I not more than 300 Ω ● Sensor II not more than 2.5 kΩ 	
Resistances correct	Resistances too high

Injectors or cold start valve leaking	
Check for leaks with injectors and cold start valve connected to ring main. Switch ignition on and off several times.	
No leaks found	Leaks found and eliminated

Inlet valves leaking despite correct adjustment	
Check compression	
Compression OK	Compression poor

CO influenced excessively by crankcase breather	
Possible causes: <ul style="list-style-type: none"> ● Too much oil in engine ● Oil dilution by fuel ● Pistons, rings and cylinders worn Repair as necessary	

Replace defective temperature sensor.

Repair engine



Handwritten notes in a rectangular box, possibly describing the diagram above.

Handwritten notes in a rectangular box, possibly describing the diagram above.

Handwritten notes in a rectangular box, possibly describing the diagram above.


Handwritten notes in a rectangular box, possibly describing the diagram above.

Handwritten notes in a rectangular box, possibly describing the diagram above.


Handwritten notes in a rectangular box, possibly describing the diagram above.

Handwritten notes in a rectangular box at the top of the page.

- 1 - Control unit
- 2 - Wiring harness - electronic
- 3 - Pressure sensor with fuel distributor
- 4 - Throttle valve actuator with distributor
- 5 - Temperature sensor in intake air distributor
- 6 - Temperature sensor in engine block
- 7 - Oxygen sensor with filter
- 8 - Ignition coil
- 9 - Ignition coil
- 10 - Cool water pump
- 11 - Cool water pump
- 12 - Voltage regulator
- 13 - Water for voltage regulator
- 14 - Water battery - voltage regulator
- 15 - Water battery
- 16 - Water battery - fuel pump
- 17 - Water battery for fuel pump
- 18 - Fuel filter for cold start device
- 19 - Water main wiring harness
- 20 - Water main wiring harness
- 21 - Water main wiring harness
- 22 - Water main wiring harness
- 23 - Water main wiring harness
- 24 - Water main wiring harness
- 25 - Water main wiring harness
- 26 - Water main wiring harness
- 27 - Water main wiring harness
- 28 - Water main wiring harness
- 29 - Water main wiring harness
- 30 - Ground connection on engine housing




Caution
 Before starting to work on
 any part of electrical system
 disconnect battery ground strap




- 1 - Control unit
- 2 - Wiring harness - electronics
- 3 - Pressure sensor with full load diaphragm
- 4 - Throttle valve switch with acceleration enrichment
- 5 - Temperature sensor in intake air distributor
- 6 - Temperature sensor on cylinder head
- 7 - Ignition distributor with trigger contacts
- 8 - Injectors
- 9 - Fuel pump
- 10 - Cold starting valve
- 11 - Ignition coil
- 12 - Voltage supply relay
- 13 - Wiring for voltage supply relay
- 14 - Wiring, battery - voltage supply relay
- 15 - Fuel pump relay
- 16 - Wiring harness - fuel pump
- 17 - Wiring between fuse box and pump relay
- 18 - Thermo switch for cold starting device
- 19 - Wires of main wiring harness
- 20 - }
- 21 - }
- 22 - } Wire connector - single
- 23 - }
- 24 - }
- 25 - }
- 26 - }
- 27 - }
- 28 - }
- 29 - }
- 30 - }
- 31 - }
- 32 - }
- 33 - }
- 34 - }
- 35 - }
- 36 - }
- 37 - }
- 38 - }
- 39 - }
- 40 - }
- 41 - }
- 42 - }
- 43 - }
- 44 - }
- 45 - }
- 46 - }
- 47 - }
- 48 - }
- 49 - }
- 50 - }
- 51 - }
- 52 - }
- 53 - }
- 54 - }
- 55 - }
- 56 - }
- 57 - }
- 58 - }
- 59 - }
- 60 - }
- 61 - }
- 62 - }
- 63 - }
- 64 - }
- 65 - }
- 66 - }
- 67 - }
- 68 - }
- 69 - }
- 70 - }
- 71 - }
- 72 - }
- 73 - }
- 74 - }
- 75 - }
- 76 - }
- 77 - }
- 78 - }
- 79 - }
- 80 - }
- 81 - }
- 82 - }
- 83 - }
- 84 - }
- 85 - }
- 86 - }
- 87 - }
- 88 - }
- 89 - }
- 90 - }
- 91 - }
- 92 - }
- 93 - }
- 94 - }
- 95 - }
- 96 - }
- 97 - }
- 98 - }
- 99 - }
- 100 - }

Caution
 Before starting to work on any part of electrical system disconnect battery ground strap



- 1 - Control unit
 - 2 - Wiring harness - electronics
 - 3 - Pressure sensor
 - 4 - Throttle valve switch
 - 5 - Temperature sensor I in intake air distributor
 - 6 - Temperature sensor II on cylinder head
 - 7 - Ignition distributor with trigger contacts
 - 8 - Injectors
 - 9 - Voltage supply relay
 - 10 - Fuel pump relay
 - 11 - Fuel pump
 - 12 - Thermo switch
 - 13 - Cold starting valve
 - 14 - Auxiliary air regulator
 - 15 - Ignition coil
 - 16 - Wiring of main harness
 - 17 - Wiring harness for fuel pump
 - 18 - Fuse box
 - 19 - Wiring for voltage supply relay
 - 20 - Wire connector, double
 - 21 - Wire connector, single
 - 22 - Wire connector, single
 - 23 - Wire connector, single
 - 24 - Wire connector, single
 - 25 - Wire connector, single
 - 26 - Ground cable pressure sensor
 - 27 - Ground connection
 - 28 - Ground connection on engine housing
- A - To battery, positive (+) terminal

Caution
 Before starting to work on any part of electrical system disconnect battery ground strap




- 1 - Control unit
- 2 - Wiring harness - electronics
- 3 - Pressure sensor
- 4 - Throttle valve switch
- 5 - Temperature sensor I in intake air distributor
- 6 - Temperature sensor II on cylinder head
- 7 - Ignition distributor with trigger contacts
- 8 - Injectors
- 9 - Voltage supply relay
- 10 - Fuel pump relay
- 11 - Fuel pump
- 12 - Thermo switch
- 13 - Cold starting valve
- 14 - Auxiliary air regulator
- 15 - Ignition coil
- 16 - Wiring of main harness
- 17 - Wiring harness - fuel pump
- 18 - Fuse box
- 19 - Wiring for voltage supply relay
- 20 - Wire connector - double
- 21 - } Wire connector - single
- 22 - }
- 23 - }
- 24 - }
- 25 - Ground connection
- 26 - Ground connection, engine housing
- 27 - Wire connector - multiple
- 28 - Wire connector - single
- 29 - Valve for exhaust gas recirculation
- 30 - Relay for exhaust gas recirculation
- 31 - Thermo switch


A - To battery positive (+) terminal

Type 4 up to July 1971

Caution
Before starting to work on any part of electrical system disconnect battery ground strap



Type 4 from August 1971
(see additional diagram on next page)



Caution
Before starting to work on any part of electrical system disconnect battery ground strap

- 1 - Control unit
- 2 - Wiring harness - electronics
- 3 - Pressure sensor
- 4 - Throttle valve switch
- 5 - Temperature sensor I in intake air distributor
- 6 - Temperature sensor II on cylinder head
- 7 - Ignition distributor with trigger contacts
- 8 - Injectors
- 9 - Voltage supply relay
- 10 - Fuel pump relay
- 11 - Fuel pump
- 12 - Thermo switch
- 13 - Cold starting valve
- 14 - Auxiliary air regulator
- 15 - Ignition coil
- 16 - Wires of the main wiring harness
- 17 - Wiring harness - fuel pump
- 18 - Fuse box
- 19 - Wiring harness - voltage supply relay
- 20 - Wire connector - single
- 21 - Wire connector - single
- 22 - Wire connector - single
- 23 - Ground connection
- 24 - Wire distributor
- A - to battery positive (+) terminal

Type 4 from August 1971 (additional wiring diagram)
 (see also diagram on preceding page)

Caution
 Before starting to work on
 any part of electrical system
 disconnect battery ground strap

